

Treatment Technologies for Site Cleanup: Annual Status Report (Ninth Edition)






Table of Contents

Notice	v
Foreword	vi
Acknowledgment	vii
Abstract	viii
Overview	1
Introduction	1
What Treatment Technologies Are Covered in This Report?	1
Source Control Treatment Technologies	2
In Situ Groundwater Treatment Technologies	2
Contents of this Report	2
Sources of Information for this Report	2
Definitions of Specific Treatment Technologies	3
Source Control Treatment Technologies	3
In Situ Groundwater Treatment Technologies	5
Section 1: Overview of RODs	7
RODs Signed by Fiscal Year	7
Source Control RODs	7
Section 2: Treatment Technologies for Source Control	9
Source Control RODs	9
In Situ Versus Ex Situ Technologies	11
Implementation Status of Treatment Technology Projects	14
Contaminants Addressed	17
Quantity of Soil Addressed	17
New Information on Established Technologies	21
Remedy Changes	22
Section 3: Innovative Applications	25
Bioremediation	27
Treatment Trains	28
Section 4: Groundwater Technologies	30
Section 5: Superfund Removal Actions	33
Section 6: Actions Under Other Federal Programs	34

Appendix A
 Superfund Remedial Actions: Treatment Technologies
 by Fiscal Year A-1

Appendix B
 Source Control Treatment Technology Summary Matrix B-1
 Groundwater Treatment Technology Summary Matrix B-35

Appendix C
 Treatment Trains with Innovative Technologies C-1

Appendix D
 Ninth Edition (April 1999): Additions, Changes, and
 Deletions from the Eighth Edition (November 1996) D-1
 Eighth Edition (November 1996): Additions, Changes, and
 Deletions from the Seventh Edition (September 1995) D-23
 Seventh Edition (September 1995): Additions, Changes, and
 Deletions from the Sixth Edition (September 1994) D-32
 Sixth Edition (September 1994): Additions, Changes, and
 Deletions from the Fifth Edition (September 1993) D-36
 Fifth Edition (September 1993): Additions, Changes, and
 Deletions from the Fourth Edition (October 1992) D-40
 Fourth Edition (October 1992): Additions, Changes, and
 Deletions from the Third Edition (April 1992) D-43
 Third Edition (April 1992): Additions, Changes, and
 Deletions from the Second Edition (September 1991) D-44
 Second Edition (September 1991): Additions, Changes, and
 Deletions from the First Edition (January 1991) D-46

Appendix E
 Superfund Remedial Actions: RODs Selecting
 Natural Attenuation E-1

Figures

Figure 1. Superfund Remedial Actions: RODs Signed by Fiscal Year	7
Figure 2. Superfund Remedial Actions: Source Control RODs by Fiscal Year	8
Figure 3. Superfund Remedial Actions: Source Control RODs Through Fiscal Year 1997 (Cumulative)	8
Figure 4. Superfund Remedial Actions: Treatment Versus On Site Containment/Off Site Disposal Decisions For Source Control Through Fiscal Year 1997	9
Figure 5. Superfund Remedial Actions: Trends for Most Frequently Selected Technologies for Source Control Through Fiscal Year 1997	10
Figure 6. Superfund Remedial Actions: Trends for Most Frequently Selected Technologies for Source Control Through Fiscal Year 1997	10
Figure 7. Superfund Remedial Actions: Cumulative Trends for Most Common Technologies for Source Control	11
Figure 8. Superfund Remedial Actions: Summary of Source Control Treatment Technologies Through Fiscal Year 1997	12
Figure 9. Superfund Remedial Actions: In Situ Technologies Versus Ex Situ Technologies by Fiscal Year	13
Figure 10. Superfund Remedial Actions: In Situ Technologies for Source Control by Fiscal Year	13
Figure 11. Superfund Remedial Actions: Status of Treatment Technologies in 1996 Versus 1998	14
Figure 12. Superfund Remedial Actions: Treatment Technologies in the Remedial Pipeline by Technology Type	15
Figure 13. Superfund Remedial Actions: Project Status of Treatment Technologies as of August 1998	16
Figure 14. Superfund Remedial Actions: Contaminants Treated by Technology Type	17
Figure 15. Superfund Remedial Actions: Estimated Quantities of Soil to Be Treated by Source Control Technologies	18
Figure 16. Superfund Remedial Actions: Average Soil Volumes by Technology	19
Figure 17. Superfund Remedial Actions: Total Volume of Soil Treated by Technology Type	20
Figure 18. Superfund Remedial Actions: Site Types for Solidification/Stabilization	21
Figure 19. Superfund Remedial Actions: Projects With a Remedy Change	22
Figure 20. Superfund Remedial Actions: Changes in Incineration Remedies	23

Figure 21. Superfund Remedial Actions: Changes in Solidification/Stabilization Remedies 24

Figure 22. Superfund Remedial Actions: Changes in Bioremediation Remedies 24

Figure 23. Superfund Remedial Actions: Technologies Listed as Innovative and Established in 1996 Versus 1998 25

Figure 24. Superfund Remedial Actions: Summary of Innovative Source Control Treatment Technologies Selected Through Fiscal Year 1997 26

Figure 25. Superfund Remedial Actions: Contaminants Treated by Bioremediation 27

Figure 26. Superfund Remedial Actions: Bioremediation Methods for Source Control 28

Figure 27. Superfund Remedial Actions: Treatment Trains with Innovative Treatment Technologies 29

Figure 28. Superfund Remedial Actions: Groundwater Remedies Through Fiscal Year 1997 30

Figure 29. Superfund Remedial Actions: In Situ Groundwater Treatment Technologies 31

Figure 30. Superfund Remedial Actions: Types of Sites Addressed by Air Sparging 31

Figure 31. Superfund Remedial Actions: Contaminants Treated by Air Sparging 32

Figure 32. Superfund Remedial Actions: Natural Attenuation for Groundwater by Fiscal Year 32

Figure 33. Superfund Removal Actions: Project Status of Treatment Technologies as of August 1998 33

Figure 34. Sample Projects Under Other Federal and RCRA Corrective Action Programs: Status of Treatment Technologies as of August 1998 34

Notice

Preparation of this report has been funded wholly or in part by the U.S. Environmental Protection Agency (EPA) under Contract Numbers 68-W5-0055 and 68-W-99-003. Mention of trade names or commercial products does not constitute endorsement or recommendation for use. The *Treatment Technologies for Site Cleanup: Annual Status Report (ASR), Ninth Edition* is available free of charge by mail or fax from:

U.S. EPA/National Service Center for
Environmental Publications (NSCEP)
P.O. Box 42419
Cincinnati, OH 45242

Telephone: (513) 489-8190 or (800) 490-9198
Fax Number: (513) 489-8695

A color version of the ASR is also available for viewing or downloading from the Hazardous

Waste Cleanup Information (CLU-IN) web site at <http://clu-in.org>.

The data for the ASR have been incorporated into EPA's REmediation And CHaracterization Innovative Technologies (EPA REACH IT) on-line searchable database at <http://www.epareachit.org>. EPA REACH IT combines the ASR data with two other EPA databases containing information on innovative treatment and characterization technologies: the Vendor Information System for Innovative Treatment Technologies (VISITT) and the Vendor Field Analytical and Characterization Technologies System (Vendor FACTS). EPA REACH IT fosters communication between technology vendors and users by providing information on the availability, performance, and cost associated with the application of treatment and characterization technologies.

Foreword

Over the next several decades, federal, state, and local governments, and private industry, will commit billions of dollars annually to clean up sites contaminated with hazardous waste and petroleum products. This planned investment will result in a continuing demand for site remediation services and technologies that provide better, faster, and cheaper environmental cleanups. The information contained in this report is designed to improve communication between technology users and those who are considering treatment technologies to clean up sites. Increased communication will help promote the use of new, less costly, and more effective technologies to address problems at Superfund and other contaminated sites. Also, the site-specific information will enable technology vendors to evaluate the market for possible site applications for the next several years.

This report documents, as of the summer of 1998, the status of treatment technology applications for soil, other solid wastes, and groundwater at sites in the Superfund program, and selected Resource Conservation and Recovery Act (RCRA) corrective action, U.S. Department of Defense

(DoD), and U.S. Department of Energy (DOE) sites. Previously titled *Innovative Treatment Technologies: Annual Status Report*, this ninth edition of the report has been renamed *Treatment Technologies for Site Cleanup: Annual Status Report* to reflect the inclusion of a broader range of treatment technologies (beyond innovative), such as off-site incineration and solidification/stabilization, to treat soil and other solid wastes. As described in the Introduction, EPA has expanded this edition to include sites using these two additional technologies, and has updated status information on more than 900 treatment technology projects. Access to more detailed project information has been made easier by incorporating the data for the treatment technology projects into a new, searchable EPA REACH IT system on the Internet. (See the Notice for more information.)

EPA plans to continue to publish annual updates on the status of more than 900 projects, and to add newly selected projects annually as well. Comments or questions concerning this report should be directed to the U.S. EPA, Technology Innovation Office (5102G), 401 M Street, SW, Washington, DC 20460, (703) 603-9910.

Acknowledgment

This document was prepared for EPA's Technology Innovation Office under Contract Numbers 68-W5-0055 and 68-W-99-003 by Tetra Tech EM Inc.

Special acknowledgment is given to the federal and state staff and other remediation professionals

listed as contacts for individual sites, for providing the detailed information in this document. Their cooperation and willingness to share their expertise on treatment technologies encourages the application of those technologies at other sites.

Abstract

This report documents the status, as of the summer of 1998, of treatment technology applications for soil, other solid wastes, and groundwater at sites in the Superfund and several other national site cleanup programs. Previously titled *Innovative Treatment Technologies: Annual Status Report*, this ninth edition of the report has been renamed *Treatment Technologies for Site Cleanup: Annual Status Report* to reflect the inclusion of a broader range of treatment technologies (beyond innovative). The data in this report were gathered from site project managers for Superfund remedial and removal sites, RCRA corrective action sites, and Departments of Defense and Energy sites. The report looks at both source control technologies (addressing soil, sludge, sediment, and other solid-matrix wastes) and innovative groundwater treatment technologies. The principle technologies to treat soil and other solid wastes tracked in the report are: on- and off-site incineration, solidification/stabilization, soil vapor extraction (SVE), thermal desorption, and ex situ and in situ bioremediation. The innovative groundwater treatment technologies included in this report are air sparging, in situ bioremediation, in situ chemical treatment, dual-phase extraction (for soil and groundwater), and permeable reactive barriers (also known as passive treatment walls).

This report provides a summary of technology applications identified for each cleanup program, and a matrix listing each site and technology used. Changes in remedies over the nine editions of the report also are listed. The report includes data on 933 treatment technology projects, 747 of which are for Superfund remedial actions. For the most frequently selected technologies in the Superfund remedial program, the report analyzes selection trends over time, contaminant groups treated, quantities of soil treated (for soil treatment technologies), and project implementation status.

This report finds that for treatment technologies at Superfund remedial action sites:

- A total of 302 projects have been completed, and another 202 are operational
- The number of innovative groundwater technologies that are operational has doubled in the past two years to 38 applications

For all source control technologies:

- More than half (59 percent) are ex situ
- 60 percent of ex situ projects have been completed
- 23 percent of in situ projects have been completed
- Average time to cleanup for ex situ technologies was 13 months, and for in situ technologies 19 months

In situ SVE is the most frequently used treatment technology (26 percent of source control projects), followed by ex situ solidification/stabilization (18 percent) and off-site incineration (14 percent). For projects with available data, the total amount of soil being treated by in situ technologies is at least three times the amount of soil for ex situ technologies (32 million versus 10 million cubic yards). Based on available data, 69 percent (29 million cubic yards) of the total volume of soil treated is being addressed by SVE.

Results on contaminants treated at Superfund sites indicate that:

- Over three-quarters of the Superfund remedial projects in the report address organics alone.
- Only one-fifth of the remedial projects address metals alone or in combination with organics.

Access to more detailed project information has been made easier by incorporating the site-specific data used as the basis for this report into the new searchable EPA REACH IT system at <http://www.epareachit.org>. An HTML version of this report is available at <http://clu-in.org>.

Overview

Introduction

The *Treatment Technologies for Site Cleanup: Annual Status Report (ASR), Ninth Edition* was prepared by the Technology Innovation Office (TIO) of the U.S. Environmental Protection Agency's (EPA) Office of Solid Waste and Emergency Response (OSWER) to document the use of treatment technologies to remediate contaminated hazardous waste sites. The report contains a list and an analysis of Superfund sites (both remedial and removal actions), Resource Conservation and Recovery Act (RCRA) corrective action sites, and other non-Superfund sites (that is, sites addressed under other federal and state programs) where treatment technologies are being used. Site managers can use this report to evaluate cleanup alternatives for similar sites. Technology vendors can use it to identify potential markets. TIO also uses the information to track progress in the application of established and innovative treatment technologies.

The treatment technologies report is usually updated annually. The eighth edition of this report published in November 1996 contained data from Superfund Records of Decision (RODs) through fiscal year (FY) 1995. This ninth edition updates and expands information provided in the November 1996 report by including data from FY 1996 and FY 1997 RODs. This document includes a list of sites and an analysis of 747 applications of treatment technologies for remedial actions, 97 applications for removal actions, 15 applications under RCRA corrective actions, and 72 applications under other federal and state programs. Information added to this update includes 69 applications of treatment technologies selected in Superfund RODs for remedial actions in FY 1996 and 51 selected in FY 1997. A ROD is the decision document used to specify the way a site, or part of a site, will be remediated. Detailed information on approximately 250 off-site incineration and solidification/stabilization projects selected in RODs from FY 1982 through FY 1997 has been added to the report which also includes information on more than 100 additional projects that have been completed since November 1996. Also in this report is information about innovative technologies being implemented at an additional 67 Superfund removal actions, six RCRA corrective actions, and 37 applications under other federal and state programs.

This report does not address sites that use nontreatment remedies, such as landfilling and capping. It contains only minimal information on sites that use pump-and-treat remedies. More information about RODs that specify these types of remedies is presented in the series of ROD annual reports published by the EPA's Office of Emergency and Remedial Response (OERR). For more information about those reports, call the RCRA/ Superfund Hotline at (800) 424-9346 (outside the Washington, D.C. metropolitan calling area) or (703) 412-9810 (inside the Washington, D.C. metropolitan calling area).

HIGHLIGHTS OF THIS REPORT

- Increase in number of treatment technology applications to 933 from 419 in previous edition, including for the first time site-specific information on 250 Superfund solidification/stabilization and off-site incineration projects.
- More detailed analysis of 747 applications of treatment technologies for Superfund remedial actions.
- For the first time, soil vapor extraction and thermal desorption are defined as established technologies because of the large number of applications and availability of cost and performance information.
- Updated database system searchable on the Internet (<http://www.epareachit.org>).

What Treatment Technologies Are Covered in This Report?

Most RODs for remedial actions address the source of contamination, such as soil, sludge, sediments, and solid-matrix wastes. These "source control" RODs select "source control technologies." Groundwater remedial action—a non-source control action—may be a component of the "source control" ROD and the treatment technologies chosen for groundwater remediation are referred to as "groundwater technologies."

Treatment technologies are alternatives to on-site containment and off-site land disposal. Established treatment technologies are those for which cost and performance information is readily available. The most frequently used established technologies are on- and off-site incineration, solidification/stabilization, soil vapor extraction (SVE), thermal desorption, and pump-and-treat technologies for

groundwater. Treatment of groundwater after it has been pumped to the surface often resembles traditional water treatment; also, due to the availability of cost and performance data on pump-and-treat groundwater remedies, the pump-and-treat groundwater remedies are considered established technologies.

SVE and thermal desorption are two established technologies that were formerly considered innovative. Their large number of applications and the amount of documentation that has recently become available on their cost and performance have resulted in their transition to established technologies.

Innovative treatment technologies are alternative treatment technologies whose limited number of applications result in a lack of data on cost and performance. In general, a treatment technology is considered innovative if it has had limited full-scale application. Often, it is the application of a technology or process to a waste site (soils, sediments, sludge, and solid-matrix waste [such as mining slag] or groundwater) that is innovative, not the technology itself. Specific innovative technologies are discussed in Section 3. This report documents the use of the following treatment technologies to treat groundwater, soils, sediments, sludge, and solid-matrix waste:

Source Control Treatment Technologies

- Bioremediation (ex situ and in situ)
- Chemical treatment
- Cyanide oxidation
- Dechlorination
- Flushing (in situ)
- Hot air injection
- Incineration (off site and on site)*
- Mechanical soil aeration*
- Neutralization*
- Open burn/open detonation*
- Physical separation
- Phytoremediation
- SVE*
- Soil washing
- Solidification/stabilization*
- Solvent extraction
- Surfactant flushing
- Thermal desorption*
- Thermally enhanced recovery
- Vitrification

In Situ Groundwater Treatment Technologies

- Air sparging
- Bioremediation (in situ)
- Chemical treatment
- Dual-phase extraction
- Oxidation (in situ)
- Permeable reactive barrier
- Well aeration (in situ)

**Established technologies*

Contents of this Report

The following sections of this report contain summary information and analyses of sites where treatment technologies are being or have been applied. Section 1 discusses remedies selected in Superfund RODs through FY 1997. Section 2 discusses all Superfund projects that implement a treatment technology for source control. Information about the types of technologies used, their status, and the contaminants treated is presented. Section 3 presents information on innovative technologies and discusses some innovative technologies in detail. Section 4 presents information about applications of in situ groundwater technologies. Section 5 provides information on Superfund removal action sites. Removal actions are usually conducted in response to a more immediate threat caused by a release of hazardous substances. Threats addressed by remedial actions are less immediate. Section 6 covers non-Superfund sites being addressed under RCRA and other federal programs.

Sources of Information for this Report

EPA initially used RODs to compile information on remedial actions, and used pollution reports, on-scene coordinators' (OSC) reports, and the OSWER Removal Tracking System to compile data on emergency response actions. The U.S. Army Corps of Engineers (USACE) Hazardous, Toxic, and Radioactive Waste (HTRW) Center of Expertise in Omaha, Nebraska, and RCRA corrective action statements of basis (SBs) were consulted to compile information on projects under federal programs. EPA then verified and updated the draft information through interviews with remedial project managers (RPM), OSCs, and other contacts for each site. The data on project status supplements data in the Comprehensive Environmental Response,

Compensation, and Liability Information System (CERCLIS), EPA's Superfund tracking system, by providing more detailed information on the specific portion of the remedy that involves a treatment technology. In addition, information about technologies and sites identified here may differ from information found in the ROD annual reports and the RODs database. Such differences are the result of changes in the remedy during the design phase of the project. The changes may not have required official documentation (that is, a ROD amendment or an explanation of significant differences [ESD]).

Definitions of Specific Treatment Technologies

This document reports on the use of the treatment technologies listed above. The technologies reported in the following sections treat contaminants in different ways. This section provides brief definitions of the 21 types of source control (primarily soil) treatment technologies, and six types of in situ groundwater technologies as they are used in this document. The source for the definitions of treatment technologies is the Remediation Technologies Screening Matrix and Reference Guide, Version 3.0, which can be viewed at the Federal Remediation Technologies Roundtable (FRTR) web site at <http://www.frtr.gov>. Pictures are provided for some of the newer innovative treatment technologies.

Source Control Treatment Technologies

EX SITU BIOREMEDIATION uses microorganisms to degrade organic contaminants in excavated soil, sludge, and solids. The microorganisms break down contaminants by using them as a food source. The end products typically are carbon dioxide and water. Ex situ bioremediation includes slurry-phase bioremediation, in which the soils are mixed in water to form a slurry to keep solids suspended and microorganisms in contact with the soil contaminants; and solid-phase bioremediation, in which the soils are placed in a cell or building and tilled with added water and nutrients. Land farming and composting are types of solid-phase bioremediation.

IN SITU BIOREMEDIATION techniques stimulate and create a favorable environment for microorganisms to grow and use contaminants as a food and energy source. Generally, this

means providing some combination of oxygen, nutrients, and moisture, and controlling the temperature and pH. Sometimes, microorganisms adapted for degradation of the specific contaminants are applied to enhance the process. Bioventing is a common form of in situ bioremediation. Bioventing uses extraction wells to circulate air with or without pumping air into the ground.

CHEMICAL TREATMENT typically involves reduction/oxidation (redox) reactions that chemically convert hazardous contaminants to nonhazardous or less toxic compounds that are more stable, less mobile, or inert. Redox reactions involve the transfer of electrons from one compound to another. Specifically, one reactant is oxidized (loses electrons) and one is reduced (gains electrons). The oxidizing agents most commonly used for treatment of hazardous contaminants are ozone, hydrogen peroxide, hypochlorites, chlorine, and chlorine dioxide.

In **CYANIDE OXIDATION**, organic cyanides are oxidized to less hazardous compounds through chemical reactions.

DECHLORINATION is a chemical reaction that removes or replaces chlorine atoms contained in hazardous compounds, rendering them less hazardous. Typically, contaminated soil is screened, processed with a crusher and pug mill, and mixed with sodium bicarbonate. The mixture is heated to above 330°C (630°F) in a reactor to partially decompose and volatilize the chlorine atoms. The volatilized chlorine atoms are captured, condensed, and treated separately.

For **FLUSHING (IN SITU)**, large volumes of water, at times supplemented with treatment compounds, are applied to the soil or injected into the groundwater to raise the water table into the contaminated soil zone. Injected water is isolated within the underlying aquifer and recovered.

With **HOT AIR INJECTION**, hot air or steam is injected below the contaminated zones to heat contaminated soil. The heating enhances the release of contaminants from the soil matrix so they can be extracted and captured for further treatment or recycling.

Both on-site and off-site **INCINERATION** use high temperatures, 870 to 1,200°C (1,600 to 2,200°F), to volatilize and combust (in the presence of oxygen) halogenated and other refractory organics in hazardous wastes. Often

auxiliary fuels are employed to initiate and sustain combustion. The destruction and removal efficiency (DRE) for properly operated incinerators exceeds the 99.99 percent requirement for hazardous waste and can be operated to meet the 99.9999 percent requirement for polychlorinated biphenyls (PCBs) and dioxins. Off gases and combustion residuals generally require treatment. On-site incineration typically uses a transportable unit; with off-site incineration, waste is transported to a central facility.

MECHANICAL SOIL AERATION agitates contaminated soil using tilling or other means to volatilize contaminants.


NEUTRALIZATION is a chemical reaction between an acid and a base. The reaction involves acidic or caustic wastes that are neutralized (pH is adjusted toward 7.0) using caustic or acid additives.

OPEN BURN (OB) and **OPEN DETONATION (OD)** operations are conducted to destroy excess, obsolete, or unserviceable (EOU) munitions and energetic materials. In OB operations, energetic or munitions are destroyed by self-sustained combustion, which is ignited by an external source such as flame, heat, or a detonation wave. In OD operations, detonatable explosives and munitions are destroyed by detonation, which is generally initiated by the detonation of an energetic charge.

PHYSICAL SEPARATION processes use different size sieves and screens to concentrate contaminants into smaller volumes. Most organic and inorganic contaminants tend to bind, either chemically or physically, to the fine fraction of the soil. Fine clay and silt particles are separated from the coarse sand and gravel soil particles to concentrate the contaminants into a smaller volume of soil that could then be further treated or disposed.

PHYTOREMEDIATION is a process that uses plants to remove, transfer, stabilize, and destroy contaminants in soil and sediment. The mechanisms of phytoremediation include enhanced rhizosphere biodegradation (takes place in soil immediately surrounding plant roots), phytoextraction (also known as phytoaccumulation, the uptake of contaminants by plant roots and the translocation/accumulation of contaminants into plant shoots and leaves),

Model of Phytoremediation



phyto-degradation (metabolism of contaminants within plant tissues), and phyto-stabilization (production of chemical compounds by plants to immobilize contaminants at the interface of roots and soil). That definition applies to all biological, chemical, and physical processes that are influenced by plants (including the rhizosphere) and that aid in cleanup of the contaminated substances. Plants can be used in site remediation, both through the mineralization of toxic organic compounds and through the accumulation and concentration of heavy metals and other inorganic compounds from soil into aboveground shoots.

SOIL VAPOR EXTRACTION (SVE) is used to remediate unsaturated (vadose) zone soil. A vacuum is applied to the soil to induce the controlled flow of air and remove volatile and some semivolatile contaminants from the soil. SVE is usually performed in situ, however, in some cases, it can be used as an ex situ technology.

FOR SOIL WASHING, contaminants sorbed onto fine soil particles are separated from bulk soil in an aqueous-based system on the basis of particle size. The wash water may be augmented with a basic leaching agent, surfactant, pH adjustment, or chelating agent to help remove organics and heavy metals.

SOLIDIFICATION/STABILIZATION (S/S) reduces the mobility of hazardous substances and contaminants in the environment through both physical and chemical means. S/S is performed both ex situ and in situ. For ex situ S/S, contaminants are physically bound or enclosed

within a stabilized mass. Ex situ S/S requires disposal of the resultant materials. In situ S/S uses auger/caisson systems and injector head systems.

SOLVENT EXTRACTION uses an organic solvent as an extractant to separate organic and metal contaminants from soil. The extractant is mixed with contaminated soil in an extraction unit. The extracted solution is then placed in a separator, where the contaminants and extractant are separated for treatment and further use. Organically-bound metals may be extracted along with the target organic contaminants.

SURFACTANT FLUSHING is the extraction of contaminants from the soil using surfactants. Surfactant flushing is accomplished by pumping the surfactant through in-place soils using an injection or infiltration process. Contaminants are leached into the groundwater, which is then extracted and treated.

For **THERMAL DESORPTION**, wastes are heated to volatilize and strip out water and organic contaminants. Typically a carrier gas or vacuum system transports volatilized water and organics to a gas treatment system. Based on the operating temperature of the desorber, thermal desorption processes can be categorized into two groups: high temperature thermal desorption (HTTD) (320 to 560°C or 600 to 1000°F) and low temperature thermal desorption (LTTD) (90 to 320°C or 200 to 600°F).


THERMALLY ENHANCED RECOVERY techniques use heat to increase the volatilization rate of semi-volatile organics and facilitate extraction. Specific types of thermally enhanced recovery techniques include contained recovery of oily waste (CROW™), radio frequency heating, steam heating or in situ steam stripping, dynamic underground stripping, in situ thermal desorption and electrical resistance heating.

VITRIFICATION uses an electric current to melt contaminated soil at elevated temperatures (1,600 to 2,000°C or 2,900 to 3,650°F). The vitrification product is a chemically stable, leach-resistant, glass and crystalline material similar to obsidian or basalt rock. The process destroys and/or removes organic materials. Radionuclides and heavy metals are retained within the vitrified product.

In Situ Groundwater Treatment Technologies

AIR SPARGING involves the injection of air or oxygen through a contaminated aquifer. Injected air traverses horizontally and vertically in channels through the soil column, creating an underground stripper that removes contaminants by volatilization. This injected air helps to flush the contaminants into the unsaturated zone, where a vapor extraction system is usually implemented in conjunction with air sparging to remove the generated vapor-phase contamination. Oxygen added to the contaminated groundwater and vadose zone soils can also enhance biodegradation of contaminants below and above the water table.

Model of an Air Sparging System




With **IN SITU GROUNDWATER BIOREMEDIATION**, substrates, nutrients, or an oxygen source (such as air), are pumped into an aquifer through wells to enhance biodegradation of contaminants in groundwater. Specific types of enhanced in situ bioremediation include biosparging and bioslurping. **DUAL-PHASE EXTRACTION**, also known as multi-phase extraction, uses a vacuum system to remove various combinations of contaminated groundwater, separate-phase petroleum product, and vapors from the subsurface. This technology applies soil vapor extraction techniques to contaminants trapped in saturated-zone soils, which are more difficult to extract than those in the unsaturated zone. In some instances, this result may be achieved by sparging the groundwater section of a well that penetrates the groundwater table. Other methods also may be employed.

OXIDATION (IN SITU) oxidizes contaminants that are dissolved in groundwater, converting them into insoluble compounds.

PERMEABLE REACTIVE BARRIERS (PRBs) also known as passive treatment walls, are installed across the flow path of a contaminated plume, allowing the water portion of the plume to flow through the wall. These barriers allow the passage of water while prohibiting the movement of contaminants by employing such agents as zero-valent metals, chelators, sorbents, and microbes. The contaminants are either degraded or retained in a concentrated form by the barrier material.

For IN SITU WELL AERATION, air is injected into a double screened well, allowing the VOCs in the contaminated groundwater to transfer from the dissolved phase to the vapor- phase by air bubbles. As the air bubbles rise to the water

Model of Permeable Reactive Barrier



surface, the vapors are drawn off and treated by a SVE system.

Section 1: Overview of RODs

As of September 1998, there are 1,193 sites on the National Priorities List (NPL). An additional 55 sites are proposed for the NPL. Up to this date, 176 sites have been deleted from the NPL. Through fiscal year (FY) 1997, approximately 1,992 records of decision (ROD) (including ROD amendments) had been signed. 1,333 RODs for remedial actions address the source of contamination, such as soil, sludge, sediments, non aqueous phase liquids (NAPLs), and solid-matrix wastes. These actions are referred to as “source control” RODs. Although not itself a source control, groundwater remedial action may also be a component of a source control ROD. Other, non-source control RODs address groundwater only or specify that no action is necessary. Figure 1 shows the number of source control RODs compared with the total number of RODs for each fiscal year since FY 1982.

RODs Signed by Fiscal Year

Since 1988, the total number of RODs signed in each fiscal year has fluctuated between about 150 and 200. The total number of source control RODs has varied between approximately 100 and 150. Source control RODs have represented between 58 percent and 74 percent of all RODs signed in each of these years. In FY 1997, source control RODs

represented 59 percent of all RODs signed that year, the second lowest percentage since FY 1984.


Added to this year’s report are data for FY 1996 and FY 1997 RODs. As shown in Figure 1, although 15 more RODs were signed in FY 1997 than in FY 1996, 10 fewer source control RODs were signed in FY 1997, indicating that a greater percentage of RODs signed in FY 1997 were groundwater only or no action RODs.

Source Control RODs

Source control RODs can be classified by the general type of technology selected: (1) RODs specifying treatment, (2) RODs specifying on-site containment or off-site disposal only, and (3) RODs specifying institutional controls or other actions (such as monitoring, or relocation of the affected community).

Figure 2 shows the number of source control RODs that fall under each category. RODs that select treatment may also include containment of treatment residues or waste from another part of the site. The percentage of RODs specifying on-site containment or off-site disposal only has increased since FY 1992. In FY 1996 and FY 1997, the percentage of RODs specifying containment/disposal only was 46 percent and 42 percent, respectively, an increase from 22 percent of source control RODs in FY 1992. Figure

Figure 1. Superfund Remedial Actions: RODs Signed by Fiscal Year




Source: EPA Office of Emergency and Remedial Response and EPA Technology Innovation Office, 1998. FY 1996 and 1997 data are preliminary.

Note: The difference between the total number of RODs (1,992) and the number of source control RODs (1,333) is the number of “groundwater treatment only” or “no action needed” RODs (total of 659). For purposes of this analysis, source media does not include: leachate, NAPL, surface water, or landfill gas.

2 also shows that since FY 1991, the number of RODs specifying other remedies such as institutional controls, monitoring, relocation or nontreatment remedies increased. In FY 1995 and FY 1997, RODs specifying other remedies were at their highest percentage, representing approximately 15 percent and 26 percent of source control RODs. Nevertheless, on a cumulative basis these other remedies remain a small portion (approximately seven percent) of all historical remedies for source control (Figure 3). Overall, for 62 percent of all source control RODs (from FY 1982 through FY


1997) at least one treatment technology for source control was selected. Although the percentage of RODs specifying on-site containment or off-site disposal only increased in FY 1996 and FY 1997, approximately 31 percent of all source control RODs signed since 1982 have selected on-site containment or off-site disposal only. This percentage is lower than the cumulative percentage (34) through FY 1995. This decrease is due to the increase in the number of RODs specifying other actions rather than an increase in the number of RODs specifying treatment.

Figure 2. Superfund Remedial Actions: Source Control RODs by Fiscal Year



Source: U.S. EPA Office of Emergency and Remedial Response and U.S. EPA Technology Innovation Office, 1998. FY 1996 and 1997 data are preliminary.

Figure 3. Superfund Remedial Actions: Source Control RODs Through Fiscal Year 1997 (Cumulative)



Source: U.S. EPA Office of Emergency and Remedial Response and U.S. EPA Technology Innovation Office, 1998. FY 1996 and 1997 data are preliminary.

Section 2: Treatment Technologies for Source Control

This section discusses the number and kinds of treatment technologies selected and used for source control in the Superfund remedial program. Source control treatment technologies are designed to treat soil, sediment, sludge, or solid-matrix wastes (in other words, the source of contamination) versus those technologies designed to treat groundwater. Groundwater technologies are discussed in Section 4. In this section, source control RODs are discussed first; however, most of the information in this section focuses on technologies, rather than RODs. It is important to note that each ROD that specified treatment may have selected more than one technology.

Source Control RODs

The Superfund Amendments and Reauthorization Act of 1986 (SARA) expressed a preference for permanent remedies (that is, treatment) over containment or disposal to remediate Superfund sites. From FY 1988 through FY 1993, at least 70 percent of source control RODs provided provisions for treatment of wastes (Figure 4). The increase was most dramatic in FY 1988. In 50

percent of RODs signed in FY 1987, some treatment for source control was selected, while some treatment was selected in 72 percent of those signed in FY 1988. However, the percentage of RODs selecting treatment has decreased each year since FY 1993. Correspondingly, there has been an increase in the number of source control RODs that specify on-site containment or off-site disposal only. In fact, in FY 1996 the percentage of source control RODs specifying on-site containment or off-site disposal (46 percent) was greater than the percentage of RODs specifying treatment (43 percent). The gap grew larger by 7 percent in FY 1997.

On-site containment includes capping or disposal of waste on site, and off-site disposal involves transportation of waste to an off-site disposal facility, usually a permitted landfill. For the past five years (FY 93-97), on-site containment accounted for an average of 74 percent of the containment/disposal number, and off-site disposal averaged 26 percent. For these five years, the number of both remedies have increased at approximately the same rate.

Figures 5 and 6 graphically depict, by fiscal year, the frequency of selection for the most often selected treatment technologies for source control: SVE, solidification/stabilization, and incineration (Figure 5), bioremediation, thermal desorption, and flushing

Figure 4. Superfund Remedial Actions: Treatment Versus On Site Containment/Off Site Disposal Decisions For Source Control Through Fiscal Year 1997



Source: U.S. EPA Office of Emergency and Remedial Response and U.S. EPA Technology Innovation Office, 1998. FY 1996 and 1997 data are preliminary.

Note: The percentages for each year may not add to 100 percent because some source control RODs specified other source control remedies.


(in situ) (Figure 6). These technologies are discussed in more detail in later sections.

As shown in Figure 5, the number of SVE, solidification/stabilization, and incineration projects peaked during FY 1990 through FY 1992 and generally have since decreased from those peak levels. There have been greater than 15 projects

implemented each year for SVE since FY 1989 with the exception of FY 1994 and FY 1995, in which the number of projects were 9 and 11, respectively.


Figure 6 shows that the number of bioremediation projects has generally increased from FY 1986 through FY 1996. Only one ROD selected

Figure 5. Superfund Remedial Actions: Trends for Most Frequently Selected Technologies for Source Control Through Fiscal Year 1997



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998.

Figure 6. Superfund Remedial Actions: Trends for Most Frequently Selected Technologies for Source Control Through Fiscal Year 1997



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998.

bioremediation for source control in FY 1997. However, that remedy was changed because a treatability study indicated that bioremediation was not able to meet the cleanup goals. Hence, there were no new starts of bioremediation projects for source control in FY 1997. Thermal desorption reached a peak of seven projects in FY 1990, FY 1991, and FY 1993 and has decreased slightly since FY 1993. The number of flushing (in situ) projects has never been greater than four in any one year, and since FY 1995, there have been no flushing (in situ) projects.

Figure 7 shows the cumulative number of applications currently being implemented for source control by technology and by year. As shown in this figure, the number of applications of several technologies relative to the total number of applications (as indicated by the thickness of the wedge for a technology relative to the total thickness for any given year) has generally remained the same in recent years. The most common applications for each fiscal year are SVE, solidification/stabilization and incineration.

In Situ Versus Ex Situ Technologies

As indicated in the overview, SVE and thermal desorption are now documented in this report as established technologies. Another major change


in the report is a focus on in situ versus ex situ technologies. Previous reports have focused solely on innovative technologies, discussed in more detail in Section 3.

In situ technologies for source control are those applications in which the contaminated medium is treated in place without excavation. Ex situ technologies require excavation of the contaminated medium and treatment either on-site or off-site, as may be the case with incineration.

Figure 8 provides a cumulative overview of in situ and ex situ treatment technologies currently in use for source control. Through FY 1997, a total of 672 treatment technologies selected in approximately 614 source control RODs specifying some treatment were being implemented. There are more technologies than RODs because some sites are implementing more than one technology.


As indicated in Figure 8, SVE (27 percent), solidification/stabilization (6 percent), and bioremediation (in situ) (5 percent) are the most common in situ technologies. The most common ex situ technologies are incineration (21 percent), which includes both off-site (14 percent) and on-site (7 percent), solidification/stabilization (19 percent), thermal desorption (8 percent), and bioremediation (ex situ) (6 percent).

Figure 7. Superfund Remedial Actions: Cumulative Trends for Most Common Technologies for Source Control



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998.

Figure 8. Superfund Remedial Actions: Summary of Source Control Treatment Technologies Through Fiscal Year 1997



Note: Data are derived from Records of Decision (RODs) for FY 1982-1997 and anticipated design and construction activities as of August 1998. A site may use more than one technology. See Figure 29 for in situ groundwater treatment technologies.

() Number of times this technology was selected or used.

* "Other" ex situ technologies are: chemical treatment, cyanide oxidation, dechlorination, flushing, mechanical soil aeration, neutralization, open burn/open detonation, physical separation, SVE (two projects), solvent extraction, and vitrification. "Other" in situ technologies are: chemical treatment, hot air injection, phytoremediation, surfactant flushing, thermal desorption (one project), thermally enhanced recovery, and vitrification.


As of August 1998, 41 percent of all treatment technologies for source control at Superfund remedial sites were in situ.

Figure 9 compares the selection of in situ technologies versus ex situ technologies for source control since FY 1982. As shown in the figure, FY 1996 marked the first year that there were more in situ technologies than ex situ technologies being implemented. In fact, in FY 1996 there were twice as many in situ technologies as ex situ technologies. In FY 1997, the trend toward in situ technologies continued with 21 in situ applications versus 18 ex situ applications. Appendix A provides the number of in situ and ex situ technologies, by technology type, for both source control and groundwater treatment by fiscal year.

Figure 10 shows the number of in situ technologies as a percentage of all treatment technologies for source control by year. As a percent of all treatment


technology applications, in situ technologies have been steadily increasing since FY 1985 as shown by the trendline. Trendlines are used in problems of prediction, also known as regression analysis. Using a regression analysis, the trendline can be extended in a chart forward or backward beyond the actual data to show a trend. In FY 1996, in situ technologies reached a high point, representing 66 percent of all source control treatment technologies implemented that year. Several factors may play a role in this upward trend. Because there is no excavation with in situ technologies, there is reduced risk from exposure to contaminated media. Also, for large sites where excavation costs for ex situ technologies run into millions of dollars, in situ technologies may be more cost effective. Also in recent years, site characterization technologies have become more sophisticated, leading to more accurate delineation of the contaminated media. With better

**Figure 9. Superfund Remedial Actions:
In Situ Technologies Versus Ex Situ Technologies by Fiscal Year**



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998.

**Figure 10. Superfund Remedial Actions:
In Situ Technologies for Source Control by Fiscal Year**



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998.

information about the nature and extent of contamination present, site managers and responsible parties can be more confident in choosing an in situ technology.

Appendix B, Source Control Technology Summary Matrix, lists each of the treatment technology projects for source control at remedial sites by EPA region. (The summary matrix also includes in situ groundwater projects, removal actions, and non-Superfund projects that will be discussed in later sections.) The EPA REACH IT on-line searchable database (see Notice on page v) contains detailed information on treatment technologies being implemented at all Superfund sites.

Implementation Status of Treatment Technology Projects

In the past two years, 105 additional treatment technology projects for source control and 29 innovative technology projects for in situ groundwater treatment have been implemented. Of these projects, 14 have already been completed.


Figure 11 shows how projects have progressed through the remedial pipeline. In August 1996,

when the eighth edition of the ASR was published, more than half – approximately 53 percent – of all projects were in the earlier stages of the remedial process (predesign, design, or being installed). As of August 1998, approximately 65 percent of all projects are now either operational or completed.

Figure 12 shows a breakdown of project status by the following technology types: ex situ source control technologies, in situ source control technologies, and groundwater technologies. As shown in Figure 12, there has been an increase in the percentage of completed projects for all three technology types. The increase is most dramatic for ex situ technologies, where the percentage of projects completed increased by 15 percent. For groundwater projects, only 24 percent of the projects were operational and none were completed in August 1996. As of August 1998, however, 51 percent of groundwater projects are operational, and four percent have been completed.

Appendix B provides a matrix that indicates the status of all projects. Figure 13 provides a summary of project status as of August 1998 by technology type. [Note: This table does include new

Figure 11. Superfund Remedial Actions: Status of Treatment Technologies In 1996 Versus 1998



Note: Source of August 1996 data was the Innovative Treatment Technologies: Annual Status Report (ASR) Eighth Edition (EPA-542-R-96-010). Data for August 1998 are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Does not include data for the following technologies: incineration (off site), mechanical soil aeration, neutralization, open burn/open detonation and solidification/stabilization (S/S) (Data for these technologies was not collected for ASR 8th edition). Includes 10 projects selected in RODs or ROD amendments for FY 1998. FY 1998 data are not comprehensive.

information on incineration (off site), solidification/stabilization, mechanical soil aeration (MSA), open burn/open detonation (OB/OD), and neutralization.] For ex situ projects, the majority (60 percent) have been completed. This percentage is primarily due to the incorporation of status data for solidification/stabilization, incineration (off site), MSA, OB/OD, and neutralization projects selected in RODs dating back to FY 1982. The eighth edition of the ASR did not contain status information for any of these projects.

EPA analyzed approximately 206 completed projects to calculate the average time to complete cleanup. The time to complete cleanup was defined as the time from start of operation to completion of a project. For ex situ technologies the average time to complete cleanup was 13 months, and for in situ technologies, 19 months.

In terms of individual technologies, the majority of projects for the most common ex situ technologies [solidification/stabilization, incineration (off site), thermal desorption, and incineration(on site)] have been completed. For these four technologies, the percent of projects completed has ranged from 55 percent to 79 percent. Bioremediation (ex situ) represents the largest number of projects (33 percent) that are operational even though it is only the fifth most common ex situ technology. This high percentage is most likely due to the length of treatment time required for bioremediation as compared with

other ex situ technologies. Although bioremediation enhances the ability of microorganisms to degrade or detoxify contaminants, the time required to reach cleanup goals is often limited by the natural degradation process. Other factors such as temperature and moisture – which are influenced by the weather – play a large role in determining the degradation rate for bioremediation. Because of these considerations, bioremediation typically requires a longer period of time for treatment compared to other ex situ technologies such as incineration, thermal desorption, or solidification/stabilization where treatment time is primarily limited by the capacity and throughput of the equipment used.

For a few technologies representing less than 10 applications each, there is little change in status. For example, in August 1996, there were 12 projects in the predesign or design phase for soil washing, solvent extraction, vitrification, cyanide oxidation, and hot air injection. As of August 1998, 10 of those projects are still in the predesign or design phase, except for two soil washing projects that have been cancelled.

The EPA REACH IT on-line searchable database presents information on project status and projected schedule as well as some brief performance and operating data on remedial, removal, and non-Superfund projects that have been completed. Data provided include periods of operation, typical pre- and post-treatment concentrations of key

Figure 12. Superfund Remedial Actions: Treatment Technologies in the Remedial Pipeline by Technology Type

	Predesign/ Design	Design Complete/ Being Installed	Operational	Completed	Total
Ex Situ Source Control Technologies					
August 1996	32%	18%	14%	36%	159
August 1998	25%	9%	15%	51%	170
In Situ Technologies					
August 1996	29%	22%	37%	13%	184
August 1998	22%	11%	48%	19%	233
Groundwater Technologies					
August 1996	40%	36%	24%	0%	45
August 1998	31%	14%	51%	4%	75

Note: Source of August 1996 data was the Innovative Treatment Technologies: Annual Status Report (ASR) Eighth Edition (EPA-542-R-96-010). Data for August 1998 are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Does not include data for the following technologies: incineration (off site), mechanical soil aeration, neutralization, open burn/open detonation and solidification/stabilization (S/S)(Data for these technologies was not collected for ASR 8th edition). Includes 10 projects selected in RODs or ROD amendments for FY 1998. FY 1998 data are not comprehensive.

**Figure 13. Superfund Remedial Actions:
Project Status of Treatment Technologies as of August 1998**

Technology	Predesign/ Design	Design Completed/ Being Installed	Operational	Completed	Total
Ex Situ Source Control Technologies					
Solidification/Stabilization	28	14	11	69	122
Incineration (off site)	6	8	6	75	95
Thermal Desorption	14	4	3	34	55
Incineration (on site)	4	2	4	36	46
Bioremediation (ex situ)	11	6	15	10	42
Soil Washing	6	1	0	1	8
Neutralization	0	0	2	3	5
Solvent Extraction	2	1	1	1	5
Dechlorination	1	1	0	2	4
Chemical Treatment	1	0	2	0	3
Mechanical Soil Aeration	0	0	0	3	3
Vitrification	2	0	0	0	2
Open Burn/Open Detonation	0	0	0	2	2
SVE	1	0	0	1	2
Physical Separation	0	0	0	1	1
Flushing (in situ)	0	0	1	0	1
Cyanide Oxidation	1	0	0	0	1
Total	77	37	45	238	397
Percentage of Ex Situ Technologies	19%	9%	12%	60%	
Percentage of All Source Control Technologies	11%	6%	7%	35%	59%
In Situ Source Control Technologies					
SVE	35	20	87	36	178
Solidification/Stabilization	15	3	4	20	42
Bioremediation (in situ)	9	5	15	4	33
Flushing (in situ)	5	0	9	1	15
Thermally Enhanced Recovery	0	0	1	1	2
Hot Air Injection	1	0	0	0	1
Phytoremediation	0	0	1	0	1
Surfactant Flushing	1	0	0	0	1
Thermal Desorption	0	0	1	0	1
Vitrification	0	0	0	1	1
Total	66	28	118	63	275
Percentage of In Situ Technologies	24%	10%	43%	23%	
Percentage of All Source Control Technologies	10%	4%	18%	9%	41%
In Situ Groundwater Technologies					
Air Sparging	9	6	23	0	38
Bioremediation (in situ)	5	1	12	1	19
Dual-Phase Extraction	4	2	2	1	9
Permeable Reactive Barrier	3	1	0	0	4
Chemical Treatment	1	1	0	1	3
Oxidation (in situ)	0	0	1	0	1
Well Aeration (in situ)	1	0	0	0	1
Total	23	11	38	3	75
Percentage of Groundwater Technologies	31%	14%	51%	4%	
Percentage of All Technologies	3%	1%	5%	<1%	10%
GRAND TOTAL	166	76	201	304	747
PERCENTAGE OF GRAND TOTAL	22%	10%	27%	41%	

Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Includes 13 projects selected in RODs or ROD amendments for FY 1998. FY 1998 data are not comprehensive.

contaminants treated, cleanup goals, operating parameters (such as retention time and additives), materials handling required, and management of residuals.

Contaminants Addressed

The data collected for this report form the basis for an analysis of the classes of contaminants treated by each technology type at remedial action sites. Figure 14 provides that information, by technology, for seven major groups of contaminants: halogenated volatile organic compounds (VOC), benzene, toluene, ethylbenzene, and xylene (BTEX), other VOCs, polychlorinated biphenyls (PCB), polynuclear aromatic hydrocarbons (PAH), other semivolatile organic compounds (SVOC), and metals. For this report, compounds are categorized as halogenated VOCs, SVOCs, or PAHs according to the lists provided in EPA's SW-846 test methods 8010, 8270, and 8310. Overall, more than three-quarters of the Superfund remedial projects address organics alone. Alternatives to treat metals are limited; only one-fifth of all projects address metals alone or in combination with organics. The EPA REACH IT on-line searchable database contains information about specific contaminants treated at each site where a treatment technology is being used.


Selecting a treatment technology for a contaminant often depends on its physical and chemical properties. For example, VOCs are amenable to treatment by certain technologies such as SVE because of their volatility. In other cases, metals, which are not volatile and do not degrade, are not amenable for treatment by SVE, thermal desorption, or bioremediation. However, because metals readily form insoluble compounds when combined with appropriate additives, such as Portland cement, solidification/stabilization is most often used for treatment of these contaminants.

As shown in Figure 14, halogenated volatiles are being treated most often by SVE. BTEX or PAH components are being treated most often by bioremediation. PCBs and other SVOCs are being treated most often by incineration. Metals are being treated almost exclusively by solidification/stabilization, with a few soil washing and flushing (in situ) projects.

Quantity of Soil Addressed

EPA analyzed the quantity of soil addressed by the various treatment technologies. Data on the quantity of media treated are available for 447 sites

Figure 14. Superfund Remedial Actions: Contaminants Treated by Technology Type



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Includes 13 projects selected in RODs or ROD amendments for FY 1998. FY 1998 data are not comprehensive.

Figure 15. Superfund Remedial Actions: Estimated Quantities of Soil to Be Treated by Source Control Technologies

Technology	Total Number of Sites	Number of Sites with Data	Quantity (cubic yards)			Total Quantity
			Minimum	Maximum	Average	
In Situ						
Bioremediation (in situ)	29	17	5,000	281,000	79,000	1,345,000
Flushing (in situ)*	15	6	19,360	1,000,000	62,000	314,000
Hot Air Injection	1	1	—	—	—	700
Solidification/Stabilization	41	30	180	207,000	43,000	1,288,000
SVE	178	123	75	6,135,000	237,000	29,107,000
Thermally Enhanced Recovery	2	1	—	—	—	200
Vitrification	1	1	—	—	—	5,000
AVERAGE			6,100	1,906,000	105,250	
TOTAL	267	179				32,057,000
Ex Situ						
Bioremediation (ex situ)	42	37	21	1,936,000	80,000	2,966,000
Chemical Treatment	3	1	—	—	—	50,000
Dechlorination	4	4	700	30,000	19,000	78,000
Flushing (in situ)	1	1	—	—	—	14,000
Incineration (off site)	94	49	5	23,000	4,000	194,000
Incineration (on site)	46	36	12	330,000	48,000	1,736,000
Mechanical Soil Aeration	3	2	3,200	12,000	8,000	15,000
Neutralization	5	2	42,000	43,000	43,000	85,000
Open Burn/Open Detonation	2	0	—	—	—	—
Physical Separation	1	1	—	—	—	8,000
Soil Washing	7	6	6,400	177,000	40,000	242,000
Solidification/Stabilization	119	76	18	1,033,000	48,000	3,655,000
Solvent Extraction	5	4	7,000	13,000	9,000	38,000
SVE	2	2	535	3,000	6,000	3,000
Thermal Desorption	55	47	250	180,000	25,000	1,153,000
AVERAGE			5,500	3,780,000	38,000	
TOTAL	389	268				10,237,000

Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Includes 13 projects selected in RODs or ROD amendments for FY 1998. FY 1998 data are not comprehensive.

* Average soil volume per project and total volume does not include data for Lipari Landfill (flushing system treating an estimated volume of 1 million cy)

of a total of 656 remedial action sites where source control treatment technologies are being used to treat soil. Typically, in situ technologies are used to address larger quantities of soil, while ex situ technologies are used to treat smaller quantities. Because quantities for in situ projects often cannot be accurately determined and many projects are not completed, the quantities in Figure 15 should be considered estimates.

For ex situ technologies, the average volume of soil treated per project ranged from approximately 4,000 cubic yards (cy) to 80,000 cy. Bioremediation (ex situ) represented the highest average volume per project followed by chemical treatment (50,000 cy). For in situ technologies,

the average volume of soil treated per project ranged from 43,000 to 237,000 cy. Bioremediation and SVE were the two in situ technologies being used to treat large sites. For example, there are four SVE projects treating sites with more than two million cy of contaminated soil. There also are three bioremediation (in situ) projects treating sites with more than 250,000 cy of contaminated soil. Also, at Lipari Landfill in New Jersey, an in situ flushing project is treating a 16-acre site with an estimated volume of one million cubic yards of soil.

EPA's calculation of the average volume per project, shown in Figure 15, did not include the data for the Lipari Landfill in situ flushing project because

that data skewed the average for that technology by more than 400 percent.


Figure 16 is a box plot of the volume of soil treated by individual technologies. Presentation of data in the box plot format is useful because it shows how the data are distributed by displaying the median (average value for all projects), 25th, and 75th percentiles as well as the largest and smallest nonoutlier values. Outliers and extreme values can also be displayed. The 25th percentiles represents the value at which 25 percent of the cases have smaller values and 75 percent have larger values. The 75th percentile represents the value at which 25 percent of the cases have larger values and 75 percent have smaller values. With a box plot, the 25th and 75th percentiles, are shown as the ends of the box. The largest and smallest nonoutlier values are shown by lines that extend from the ends of the box. Outliers represent values that are between one-and-a-half and three box lengths from the top or bottom of the box. Extreme values, which are values greater than three box lengths from the top or bottom of the box, are not shown on Figure 16.

As shown in Figure 16, the median value for the volume of soil per project for all technologies was below 50,000 cy. This value indicates that for at

least 50 percent of the sites being addressed by treatment technologies, the volume of soil treated is 50,000 cy or less. However, the range of values as shown by the length of the box and whiskers for SVE and bioremediation (in situ) was much greater than those for all other technologies. The 75th percentile value for SVE and bioremediation (in situ) is above 100,000 cy, indicating that the volume being treated by these technologies exceeded 100,000 cy for 25 percent of the projects for which data were available. In contrast the median and range for the volumes of soil treated by other technologies, such as solidification/stabilization (both in situ and ex situ), incineration (both on site and off site), thermal desorption, and bioremediation (ex situ), are much smaller than for either SVE or bioremediation (in situ). The box plot reaffirms the assertion that in situ technologies are typically used to treat larger sites.

As shown in Figure 16, the median value for volume of soil per project for solidification/stabilization (both in situ and ex situ), incineration (both on site and off site), thermal desorption, and bioremediation (ex situ) was below 30,000 cy. The largest range in soil volumes for these technologies was for projects

Figure 16. Superfund Remedial Actions: Average Soil Volumes by Technology



Note: Extreme values (three box lengths from the top or bottom of box) are not included. Outliers are shown as circles. N equals the number of data points. Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998.

implementing incineration (on site). It is interesting to note that there were a number of incineration (on site) projects in which the soil volume exceeded 120,000 cy. This high volume indicates that in some cases for very large volumes of soil it may be less costly to use incineration (on site). On the other hand, for projects implementing thermal desorption, the range of volumes was much smaller, with the larger projects approaching 80,000 cy. For projects in which waste was incinerated off-site, the volume of soil treated and the range of volumes treated was very small relative to the other technologies displayed in Figure 16, indicating that incineration (off site) is typically used for relatively small volumes (less than 5,000 cy). In fact, nearly 82 percent of the sites implementing incineration (off site) for which data are available reported treating volumes of less than 5,000 cy.


Figure 17 shows the total volume being treated by each technology type. As shown in Figure

17, a majority of the soil volume is treated by SVE.

EPA also analyzed the average quantity of soil treated by year for each technology to identify any trends or changes in the average volume of soil treated. For some of the most common technologies, bioremediation (ex situ and in situ), flushing (in situ), SVE, thermal desorption, and solidification/stabilization (in situ), the average volume of soil treated per project has tended to increase over the years. However, there has been some fluctuation. For example, the average volume per project in FY 1988 was approximately 20,000 cy for thermal desorption. However, in FY 1994 the average volume was about half of that, at approximately 11,000 cy. In FY 1995, the average volume increased to approximately 46,000 cy.

For incineration and solidification/stabilization (ex situ), the average volume of soil treated per project has tended to decrease over the years.

**Figure 17. Superfund Remedial Actions:
Total Volume of Soil Treated by Technology Type**



Note: Data are derived from Records of Decision (RODs) for FY 1982-1997 and anticipated design and construction activities as of August 1998. Includes 13 projects selected in RODs and ROD amendments for FY 1998. FY 1998 data are not comprehensive. "Other (in situ)" technologies include: hot air injection, thermally enhanced recovery and vitrification. "Other (ex situ)" technologies include: chemical treatment, dechlorination, ex situ flushing, physical separation, soil washing, and ex situ SVE.

New Information on Established Technologies

As mentioned earlier, this year's report includes updated data on incineration (off site), solidification/stabilization, MSA, OB/OD, and neutralization projects. Information on these established technologies for ASR versions prior to this ninth edition was based on a review of RODs rather than on interviews with regional or state staff. Therefore, the only information for sites using these established technologies was the name of the site and the year the ROD was signed. Previous versions of the ASR did not reflect any changes in the remedy that may have occurred during the design phase of the cleanup and did not report on the implementation status of these established technology projects. The eighth edition of the ASR did update the data for incineration (on site) projects. This ninth edition of the report updates the data for incineration (off site), solidification/stabilization, MSA, OB/OD, and neutralization to make the report comprehensive in terms of all treatment (both established and innovative) technologies as well as any remedy changes that have occurred throughout

the remedial process during the previous years.


Figure 18 shows the site types treated by solidification/stabilization projects. Surface impoundments/lagoons, metal ore smelting/recycling, manufacturing process, and waste disposal/management sites are most frequently addressed by solidification/stabilization.

Additional new information in this report includes data on the volume of contaminated media treated by incineration (off site) and solidification/stabilization. As mentioned earlier, Figure 15 indicates that the average volume of soil treated per project was significantly lower for incineration (off site)(approximately 4,000 cy) versus incineration (on site)(approximately 48,000 cy).

The difference in average volume treated is most likely related to cost. Incineration (off site) is cost-effective only for small volumes of contaminated soil because of the cost of transporting waste off-site.

For solidification/stabilization projects, the volume of soil treated was roughly the same regardless of whether the technology was applied in situ or ex situ. The data collected for solidification/stabilization projects also indicate that most projects

Figure 18. Superfund Remedial Actions: Site Types for Solidification/Stabilization



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Includes three projects selected in RODs or ROD Amendments for FY 1998. FY 1998 data are not comprehensive. Does not include instances in which the number of projects with the same type was less than six. Projects can have more than one site type.

used inorganic binders, primarily Portland cement to solidify and stabilize the waste.

Remedy Changes

As indicated in Section 1, remedies selected for Superfund remedial actions are documented through a ROD. When a remedy is changed, the change can be documented through a second ROD, a ROD amendment, or an ESD. A ROD amendment can also be used to add a new remedy. In some cases, a decision document is not necessary to document a change if the new remedy was included in the original ROD as a contingency. Remedy changes often occur during the predesign or design phase of a project when new information about site characteristics are discovered or treatability studies for the selected technologies are completed.

Appendix D provides a list of sites tracked by this series of annual reports where remedy changes have occurred. For each remedy change, Appendix D documents the original remedy, the new or alternative remedy selected, the primary reasons for the change, and the decision document, if any, used to document the change. The appendix only lists a change in treatment technologies tracked by the nine editions of this report. It is not a comprehensive list of changes in Superfund RODs.

This report documents approximately 248 (235 source control and 13 groundwater) projects where remedy changes or deletions involving treatment technologies have occurred. In other words, those responsible for the site determined that the

treatment technology selected originally was no longer the appropriate remedy for that site. For some projects the new remedy or alternative selected was an innovative or established technology, or containment, including capping, or excavation and off-site disposal. For some projects, the alternative had not been determined.


Those 248 projects do not include 24 projects under which another treatment technology was added at a site. In a number of cases, another technology was added to an existing technology, either to enhance the original technology or to treat another area of the site.

Figure 19 shows the percent of projects tracked by this report that are continuing with the original remedy versus the percentage of projects that have experienced a remedy change. Overall, the 248 projects where the remedy has changed represent approximately 26 percent of all treatment technologies tracked by this report. Consequently, for the majority of projects (74 percent), the remedy has remained unchanged.

As indicated, Appendix D provides the primary reasons cited for a remedy change. In some cases, reasons related to the technology such as the cost or performance were cited. In other cases, the change was made for other reasons that were not attributable to the technology such as revised cleanup goals or changes in conditions at the site such as contaminants at the site that were naturally attenuating.

Figure 19 shows the percentage of projects in which the reason cited was attributable to the technology versus the percentage of projects experiencing a change for reasons other than the technology. As

Figure 19. Superfund Remedial Actions: Projects With a Remedy Change



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 that selected treatment technologies for source control and innovative technologies for groundwater and anticipated design and construction activities as of August 1998. Includes 13 projects selected in RODs or ROD amendments for FY 1998. FY 1998 data are not comprehensive. Does not include RODs selecting pump-and-treat or other aboveground treatment for groundwater.


shown in Figure 19 for approximately half of the projects experiencing a remedy change, the change was due to problems with the original treatment technology such as an inability to meet treatment goals.

During the effort to update information on incineration (off site) and solidification/stabilization projects that were selected in RODs dating back to FY 1982, a large number of remedy changes involving these projects were discovered and are documented in this report.

Figures 20 through 22 compare the number of RODs in which incineration, solidification/stabilization, or bioremediation was selected and the actual number of such projects implemented respectively from FY 1982 through FY 1997. The differences between the number selected and the number implemented is the result of changes in the remedy that occurred during the remedial process. For most years, as the figures show, the number of incineration, solidification/stabilization, and bioremediation technologies implemented is slightly less than the number selected in RODs for most years. The gap between incineration projects selected and those implemented (Figure 20) is greatest for FY 1989 through FY 1991. For solidification/stabilization technologies (Figure 21)

the widest gap occurred over a longer time frame, from FY 1988 through FY 1993. In both cases, the years showing the largest gaps are years in which incineration and solidification/stabilization were selected in RODs most often. However, the gaps between the number of times the technologies were selected and the number of times they were implemented generally decreased after 1994, coinciding with an overall decrease in the number of projects for which these technologies were selected. The decreased gaps may have a number of causes. For example, in the years in which the greatest differences were observed (FY 1988 through FY 1993), many innovative treatment technologies were relatively untried or unavailable. Therefore, incineration and solidification/stabilization were the two primary conventional treatment options available to site managers. As knowledge of the capabilities of other remedial options became more widespread, project managers re-evaluated initial remedy selections, adjusting them on the basis of new information. Containment or off-site disposal were the most frequent substitutes for the technologies originally selected, although thermal desorption, SVE, and other treatment technologies also were selected. (Appendix D of this report provides a table that lists the projects for which technologies were changed).

Figure 20. Superfund Remedial Actions: Changes in Incineration Remedies




Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. The differences between the number selected and the number implemented is the result of changes in the remedy that occurred during the remedial process. Includes remedies that have been added or dropped.

For most years, the difference between the number of bioremediation projects selected and the number actually implemented is relatively small (Figure 22), even though the number of bioremediation projects selected increased steadily from FY 1988 through FY 1996. Half of the time, the number of


bioremediation projects implemented was equal to or greater than the number selected. The gap between the number of times the technology was selected and the number of times it was implemented widened after 1994, but the gap remained fewer than two to four projects.

Figure 21. Superfund Remedial Actions: Changes in Solidification/Stabilization Remedies



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. The differences between the number selected and the number implemented is the result of changes in the remedy that occurred during the remedial process. Includes remedies that have been added or dropped.

Figure 22. Superfund Remedial Actions: Changes in Bioremediation Remedies



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. The differences between the number selected and the number implemented is the result of changes in the remedy that occurred during the remedial process. Includes remedies that have been added or dropped.

Section 3: Innovative Applications

This section discusses innovative treatment technologies. In the Foreword, innovative technologies were defined as treatment technologies whose use is inhibited by lack of data on cost or performance. For the first time, SVE and thermal desorption, formerly defined as innovative, are now categorized as established in this report. The eighth edition of the ASR, published in 1996, considered SVE and thermal desorption as transitional because of the large number of applications of those

technologies. They have been reclassified in this report as established because several reports and case studies have been published documenting the cost and performance of both SVE and thermal desorption. Figure 23 lists the technologies that were categorized as innovative and established in the eighth edition ASR (1996) versus those in this report. The Federal Remediation Technologies Roundtable (FRTR) has published 140 case studies on a wide range of treatment technologies which are now available for viewing on-line or downloading from the FRTR web site at <http://www.frtr.gov>. Of these, 27 pertain to SVE and 12 pertain to

Figure 23. Superfund Remedial Actions: Technologies Listed as Innovative and Established In 1996 Versus 1998

ASR 8th Edition 1996	ASR 9th Edition 1998
Innovative Source Control Technologies	
Bioremediation (ex situ) - Composting	Bioremediation (ex situ) - Biopile
Bioremediation (ex situ) - Land Treatment	Bioremediation (ex situ) - Composting
Bioremediation (ex situ) - Other	Bioremediation (ex situ) - Land Treatment
Bioremediation (ex situ) - Slurry-Phase	Bioremediation (ex situ) - Other
Bioremediation (ex situ) - Solid-Phase	Bioremediation (ex situ) - Slurry-Phase
Bioremediation (in situ) - Bioventing	Bioremediation (ex situ) - Solid-Phase
Bioremediation (in situ) - Lagoon	Bioremediation (in situ) - Bioventing
Bioremediation (in situ) - Other	Bioremediation (in situ) - Lagoon
Chemical Treatment	Bioremediation (in situ) - Other
Contained Recovery of Oily Wastes (CROW)	Chemical Treatment
Cyanide Oxidation	Changed to: Thermally Enhanced Recovery
Dechlorination	Cyanide Oxidation
Flushing (in situ)	Dechlorination
Hot Air Injection	Flushing (in situ)
Physical Separation	Hot Air Injection
	Physical Separation
	Phytoremediation
Plasma High Temperature Recovery	Remedy no longer being implemented
SVE	Now Classified as Established
Soil Washing	Soil Washing
Solvent Extraction	Solvent Extraction
	Surfactant Flushing
Thermal Desorption	Now Classified as Established
Vitrification	Vitrification
Established Source Control Technologies	
Incineration (off site)	Incineration (off site)
Incineration (on site)	Incineration (on site)
Mechanical Soil Aeration	Mechanical Soil Aeration
Neutralization	Neutralization
Open Burn/Open Detonation	Open Burn/Open Detonation
	SVE
Solidification/Stabilization	Solidification/Stabilization
	Thermal Desorption
In Situ Groundwater Technologies	
Air Sparging	In Situ Air Stripping (Air Sparging)
	Bioremediation (in situ) - Bioslurping
	Bioremediation (in situ) - Biosparging
Bioremediation (in situ) - Groundwater	Bioremediation (in situ) - Groundwater
Dual-Phase Extraction	Dual-Phase Extraction
Oxidation (in situ)	Oxidation (in situ)
Passive Treatment Wall	Changed to: Permeable Reactive Barrier
Well Aeration (in situ)	Well Aeration (in situ)

thermal desorption. The case studies were developed by EPA, DoD, and DOE. The case studies and abstracts present available cost and performance information for full-scale remediation efforts and several large-scale demonstration projects. The case studies contain information on site background and setting, contaminants and media treated, technology, cost and performance, and points of contact for the technology application. The studies contain varying levels of detail, reflecting the differences in the availability of data and information.


Although SVE and thermal desorption are no longer included in the innovative category, there are several innovative enhancements or adaptations of these technologies. For example, SVE can be enhanced

using pneumatic fracturing or a variety of thermal methods. Additional information on enhancements for SVE systems is contained in EPA's Soil Vapor Extraction (SVE) Enhancement Technology Resource Guide (EPA-542-B-95-003) and EPA's Analysis of Selected Enhancement for Soil Vapor Extraction (EPA-542-R-97-007).

Figure 23 also shows the use of three innovative technologies that were not included in the eighth edition ASR because they had not been selected in RODs; biosparging, phytoremediation, and surfactant flushing.

Figure 24 provides an overall picture of the number and type of innovative and established technologies used for source control.

**Figure 24. Superfund Remedial Actions
Summary of Innovative Source Control Treatment Technologies
Selected Through Fiscal Year 1997**



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Includes 13 projects selected in RODs or ROD amendments for FY 1998. FY 1998 data are not comprehensive.


As shown in Figure 24, innovative technologies represent approximately 18 percent of all technologies for source control. Bioremediation comprises most of the innovative technology applications (75). Other innovative technologies include flushing (in situ), phytoremediation, soil washing, solvent extraction, and vitrification.

Bioremediation

Contaminants treated by bioremediation are shown in Figure 25. The contaminants treated most often

are BTEX compounds; PAHs are the SVOCs addressed most frequently; and halogenated VOCs are being treated at 43 sites. Currently, 75 projects are implementing various forms of bioremediation for source control. Figure 26 illustrates the types of bioremediation for source control. Land treatment is the most common form of ex situ bioremediation with 29 projects, followed by composting (six projects). Based on available data, bioventing has been specified for 19 of the 33 in situ soil bioremediation remedies.

Figure 25. Superfund Remedial Actions: Contaminants Treated by Bioremediation*




* Includes in situ groundwater technologies

Note: At some sites, treatment is for more than one contaminant. Treatment may be planned, ongoing, or completed.

Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Includes six projects selected in RODs or ROD amendments for FY 1998. FY 1998 data are not comprehensive.

Figure 26. Superfund Remedial Actions: Bioremediation Methods for Source Control



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Includes four projects selected in RODs or ROD amendments for FY 1998. FY 1998 data are not comprehensive.

Treatment Trains


In some cases, several innovative and established technologies may be used together in treatment trains, which are either integrated processes or a series of treatments that are combined in sequence to provide the necessary treatment. Seventeen remedial sites use treatment trains for source control.

Figure 27 identifies specific treatment trains used in remedial actions. Appendix C provides the names of sites that use treatment trains. Innovative treatment technologies may be used with established technologies or with other innovative technologies. The most common treatment trains are dechlorination preceded by thermal desorption, soil washing followed by

aboveground bioremediation (usually slurry-phase treatment) and bioremediation followed by solidification/stabilization. Technologies may be combined to reduce the volume of material that requires further treatment; to prevent the emission of volatile contaminants during excavation and mixing; or to treat multiple contaminants in a single medium.

This year's report documents 17 treatment trains involving innovative technologies. This number is down from 32 treatment trains documented in the ASR eighth edition. The decrease was the result of classifying SVE and thermal desorption as established technologies, as well as some technologies that have been changed or cancelled.

**Figure 27. Superfund Remedial Actions:
Treatment Trains with Innovative Treatment Technologies**



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Includes one project selected in a ROD amendment for FY 1998. FY 1998 data are not comprehensive.

Section 4: Groundwater Technologies

Groundwater treatment remedies include conventional pump-and-treat and in situ treatment, or a combination of both. Figure 28 shows the overall types of groundwater treatment remedies selected. Groundwater treatment remedies have been selected for 663 sites. Of these, 588 sites are implementing pump-and-treat systems alone, and 39 sites are using pump-and-treat systems and in situ treatment, either for the same area of the site or for different areas. In situ treatment alone has been selected as a single remedy at 36 sites to treat groundwater contamination. For some of these sites, it is possible that pump-and-treat is being conducted at another part of the site.

Figure 29 lists the specific types of in situ treatments selected. More detail on their implementation status is in Figure 13 (see p. 16).

EPA has selected in situ treatment of groundwater 75 times at 65 remedial sites. EPA selected in situ treatment of groundwater for more than 26

remedial sites in FY 1996 and FY 1997. More than half of these projects are in the operational phase. Completion of these projects is expected to require 5 to 20 years. The EPA REACH IT on-line searchable database provides more detailed information for each in situ groundwater application at Superfund remedial action sites. Appendix A lists the number of in situ groundwater treatment technologies selected each year. The summary matrix in Appendix B provides site names, technologies, and project status.


Figure 30 indicates the types of sites addressed by air sparging. Vehicle maintenance/fuel lines/storage/spills and manufacturing process sites are most frequently addressed by this technology. Contaminants treated by air sparging are shown in Figure 31. Halogenated VOCs are the contaminants treated most frequently.

In recent years, an increasing number of RODs have specified natural attenuation as a remedy for groundwater contamination.

Figure 32 shows the number of RODs that selected natural attenuation for groundwater at Superfund

**Figure 28. Superfund Remedial Actions:
Groundwater Remedies Through Fiscal Year 1997**

Total Sites with Groundwater Treatment Remedies = 663



Note: Pump-and-treat remedy data based on Records of Decision (RODs) for FY 1982–1997; in situ treatment data based on anticipated design and construction activities as of August 1998. Includes four projects selected in RODs or ROD amendments for FY 1998. FY 1998 data are not comprehensive.

Source: U.S. EPA Office of Emergency and Remedial Response, 1998. FY 1996 and 1997 data are preliminary.

remedial action sites. As shown in the figure, the selection of natural attenuation has steadily increased since FY 1985. EPA's Office of Emergency and Remedial Response (OERR) analyzed FY 1982 through FY 1994 RODs selecting natural attenuation. The analysis revealed that the most common reason cited for selecting

natural attenuation was low or decreasing contaminant concentrations at the site. The analysis also indicated that the most prevalent contaminant found at these sites was VOCs.


EPA recently finalized guidelines on the use of natural attenuation to remediate groundwater. Use

Figure 29. Superfund Remedial Actions: In Situ Groundwater Treatment Technologies

Technology	Number of Projects Selected
Air Sparging	38
Bioremediation (in situ) - Groundwater	16
Dual-Phase Extraction	9
Permeable Reactive Barrier	4
Chemical treatment	3
Bioremediation (in situ) - Biosparging	2
Bioremediation (in situ) - Bioslurping	1
Oxidation (in situ)	1
Well Aeration (in situ)	1
TOTAL	75

Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998.

Figure 30. Superfund Remedial Actions: Types of Sites Addressed by Air Sparging




Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Includes one project selected in a ROD amendment for FY 1998. FY 1998 data are not comprehensive. Projects can have more than one site type. Does not include instances in which the same site types was less than three.

of Monitored Natural Attenuation at Superfund, RCRA Corrective Action, and Underground Storage Tank Sites, OSWER Directive Number 9200.4-17 is available by calling 800-424-9346 or


703-412-9810, or on the Internet at <http://www.epa.gov/swrust1/directiv/d9200417.htm>. Appendix E lists the sites selecting natural attenuation.

Figure 31. Superfund Remedial Actions: Contaminants Treated by Air Sparging



Note: Data are derived from Records of Decision (RODs) for FY 1982–1997 and anticipated design and construction activities as of August 1998. Includes one project selected in a ROD amendment for FY 1998. FY 1998 data are not comprehensive. There may be more than one contaminant group per project.

Figure 32. Superfund Remedial Actions: Natural Attenuation for Groundwater by Fiscal Year



Source: U.S. EPA Office of Emergency and Remedial Response, 1998. FY 1996 and 1997 data are preliminary.

Section 5: Superfund Removal Actions

Removal actions are usually conducted in response to a more immediate threat caused by a release of hazardous substances than threats addressed by remedial actions. Approximately 5,500 removal actions have been undertaken to address these more immediate threats. To date, innovative treatment technologies have been used in relatively few removal actions. The treatment technologies addressed in this report have been used 97 times in 54 removal actions (Figure 33). The eighth edition of the ASR documented only 33 removal actions using innovative technologies. The increase in removal actions documented in this report is primarily the result of a more comprehensive effort to collect data.

Figure 33 indicates that 54 percent of removal projects that involve treatment technologies have

been completed. Since removal actions are responses to an immediate threat, and often involve smaller quantities of hazardous wastes than remedial activities, the implementation of the technology may progress faster at a removal site than at a remedial site.

As removal actions involve smaller quantities of waste or immediate threats, they require quick action to alleviate the hazard. Often, such activities do not lend themselves to on-site treatment or innovative technologies. In addition, SARA does not establish the same preference for innovative treatment for removals as it sets forth for remedial actions.

The EPA REACH IT on-line searchable database provides more detailed information for each application of an innovative technology at a removal site. The summary matrix in Appendix B lists each removal site and treatment technology.

Figure 33. Superfund Removal Actions: Project Status of Treatment Technologies as of August 1998

Technology	Predesign/ Design	Design Complete/ Not Installed/Being Installed/ Installed	Operational	Completed	Total
Source Control Technologies					
SVE	1	3	15	10	29
Bioremediation (in situ)	0	2	18	6	26
Bioremediation (ex situ)	0	0	2	13	15
Thermal Desorption	0	0	0	6	6
Chemical Treatment	0	0	0	5	5
Soil Washing	0	0	0	3	3
Dechlorination	0	0	0	2	2
Solvent Extraction	0	0	0	2	2
Vitrification	0	0	0	2	2
TOTAL	1 (1%)	5 (6%)	35 (39%)	49 (54%)	90
In Situ Groundwater Technologies					
Air Sparging	0	2	1	1	4
Bioremediation (in situ)	0	0	1	0	1
Bioremediation (in situ)-Bioslurping	0	0	1	0	1
Bioremediation (in situ)-Biosparging	0	1	0	0	1
TOTAL	0 (0%)	3 (43%)	3 (43%)	1 (14%)	7

Note: Data based on interviews conducted in FY 1988 with EPA Superfund Removal Branch Chiefs and On-Scene Coordinators for each region and anticipated design and construction activities as of August 1998.

Section 6: Actions Under Other Federal Programs

Innovative technologies also are being conducted under federal programs other than Superfund. Many of those projects are conducted at DoD and DOE facilities. These projects were identified through various sources of information, including discussions with DoD and DOE personnel, and should not be considered exhaustive. The RCRA corrective action sites using an innovative technology were identified through the review of SBs, which are decision

documents prepared for some actions at corrective action sites. Because innovative technologies likely have been used at other RCRA sites, but not documented in statements of basis (SBs), the list in this report should not be considered complete. Figure 34 summarizes the types of innovative treatment technologies and the number of projects, and indicates the status of each. The summary matrix in Appendix B lists the name of each site, the technology selected, and the status of the project. The EPA REACH IT on-line searchable database provides more detailed information for each application.

Figure 34. Sample Projects Under Other Federal and RCRA Corrective Action Programs: Status of Treatment Technologies as of August 1998

Technology	Predesign/ Design	Design Complete/ Not Installed/Being Installed/Installed	Operational	Completed	Total
Other Federal Programs					
Bioremediation (in situ)*	1	2	11	5	19
SVE	1	3	8	6	18
Bioremediation (ex situ)	1	1	3	9	14
Thermal Desorption	0	0	1	4	5
Air Sparging	0	1	1	2	4
Vitrification	0	0	2	2	4
Incineration (off site)	1	0	0	1	2
Soil Washing	0	0	0	2	2
Dual-Phase Extraction	0	0	1	0	1
Flushing (in situ)	0	0	0	1	1
Well Aeration	1	0	0	0	1
Dechlorination	0	0	0	1	1
TOTAL	5 (7%)	7 (10%)	27 (37%)	33 (46%)	72
RCRA Corrective Action					
SVE	1	1	7	0	9
Bioremediation (in situ)*	0	2	0	0	2
Bioremediation (ex situ)	1	0	0	0	1
Air Sparging	0	0	1	0	1
Thermal Desorption	0	1	0	0	1
Well aeration (in situ)	0	0	1	0	1
TOTAL	2 (13%)	4 (27%)	9 (60%)	0 (0%)	15

Note: Data based on interviews conducted in FY 1988 with EPA RCRA Corrective Action, DoD, and DOE points of contact for each site, and anticipated design and construction activities as of August 1998.

* Includes in situ groundwater treatment.